



LPR support guide manual.

V. 1.0.0



If you having some issues with LPR, please address the online support.


You will find contact information, on the last page of this manual.

Provide us with some info:


- 1. Camera model and serial number.
- 2. Camera firmware/encoding number and build.
- 3. Camera Image settings.
- 4. Mounting conditions.
- 5. Country.
- 6. Image of problem (or video, if necessary).
- 7. Problem.

Collecting info.

1. You can see camera model and serial number on camera, on camera box or online.




2. Camera firmware/encoding number and build.




3. Camera Image settings: Exposure Settings, Day/Night Switch, Backlight Settings.










4. Mounting conditions. Specifically height of camera (H) and Length from the camera pole to the road (L).



- 5. Country of mounting.
- 6. Image of problem (or video, if necessary).
- 7. Your problem. Is it reproduces itself at certain conditions. What steps we must do to retrace it.



Contact information:

Headquarters Technical Support.

Email: support@hikvision.com