NVR Champ Release Note

Version 3.0.0.63 release date_2016.05

Release Version 3.0.0 (2016/05)

Modules

Floadics			
Item			Version
FW	NVR	NVC-2080	03.00.0000.0063
		NVC-2160	
		NVC-2080P	
		NVC-2160P	
		NC-2080	
		NC-2160	
		NC-2080P	
		NC-2160P	
	Camera Package		DP v4.11
Application	Install Wizard Remote Live Viewer Playback System Backup System Verification Tool Offline License Tool		2.3.1
			2.3.1
			2.3.1
			2.3.1
			2.3.1
			2.3.1
Document	Local User manual		3.0.0
	Remote User manual		3.0.0
	QSG		3.0.0

New Features

> 2nd stream record - Dual record

Allow system to operate dual record with both streams.

> H.265 Support

H.265 support on remote client only with supported cameras.

- > Support Hungarian
- Dual Monitor

User can enjoy dual monitors with different layout on local client.

> Local IPC image preview

Allow user to manage camera easily.

Local IPC Motion

New Motion detection added.

- Local IPC firmware upgrade, IPC reboot and reset to default
- > UPnP Support

User can mass upgrade SNVRs/ IPCs in one time by IPInstaller in remote PC.

NVR Champ Release Note

Version 3.0.0.63 release date_2016.05

Bugs Fixed

- 1. Emergency record will start when stop at first time login and switch to playback.
- 2. WAN file backup timeout when transferring large files is fixed.
- 3. WAN playback performance is enhanced by adding new NUPP command "NEXTGOP".
- 4. Local joystick support is merged back.
- 5. Local audio support in 2nd stream.
- 6. Fix local display "splash" issue that happens sometimes.
- 7. Fix local display showing FPS without decoded issue that happens sometimes.
- 8. Fix local backup POS sometimes can't show Chinese.
- 9. Fix remote playback can't use "select folder" to show POS.
- 10. Local audio will disappear when monitor "unplug and plug" in solo is fixed.
- 11. Drag and Drop will sometime malfunction during high CPU usage is fixed.
- 12. Fix local backup issue, record operation sequence.

Known Issues

- 1. User needs to use client pack 6.1.705.5 for new features to avoid failure.
- 2. To change camera order in liveview, user needs to click grid more than 2 seconds until mouse cursor change icon for drag and drop.